

.....  
PURCHASED FROM

.....  
DATE OF PURCHASE

.....  
MODEL NO

.....  
OWNERS NAME

.....  
ADDRESS

.....  
.....

Perforation

**Accurist Helpline**  
**020 7447 3945**

Further information or instructions can be obtained  
from the Accurist Helpline during office hours Monday to Friday.

Folding

**Accurist**  
**M E A N T I M E**

Quartz Analogue  
Watch Setting Instructions

**This booklet contains setting instructions for the Accurist Quartz series of watches.**

**Further information**

The latest setting instructions, technical manuals and interactive instructions are available from our web site at [www.accurist.co.uk](http://www.accurist.co.uk)

When on the web site please refer to 'After sales service/download manuals'


The Accurist technical helpline is also available during office hours: +44 (0)20 7447 3941



## Contents

|   |    |
|---|----|
| <b>Quartz Analogue Operating Instructions</b> | 5  |
| <b>Care of your watch</b>                     | 12 |
| <b>Bracelet Adjustment</b>                    | 16 |
| <b>International Service Agents</b>           | 18 |
| <b>Resistance to water</b>                    | 21 |
| <b>Accurist Quartz Guarantee</b>              | 26 |
| <b>After Sales Service</b>                    | 28 |
| <b>Payment &amp; Postage Instructions</b>     | 29 |

## Quartz Analogue Operating Instructions




**Please note:** The second hand will not start moving until the crown has been returned to Position A.

**To set the time:**

1. Gently pull out crown to Position B.
2. Turn crown either way to correct time.
3. Push in crown to Position A.

Quartz Analogue Operating Instructions continued...  
**For Calendar Models**




**To set the calendar/date:**

1. Gently pull out crown to Position B.
2. Turn crown anti-clockwise to adjust date, clockwise to adjust the day.
3. Push in crown to Position A.

**Note:** The Day will start to change at 11.25 p.m. and complete its change by 12 0' clock midnight. The Date will start to change at 12 0' clock midnight and complete its change by 4 a.m. Day/Date models have Bi-Lingual day settings; if you select English, the watch will continue to display in English.

Quartz Analogue Operating Instructions continued...  
**For Alarm Models**



**To set the alarm:**

1. Gently pull out crown to Position B.
2. Turn crown clockwise to adjust the alarm indicator hand.
3. Push in crown to Position A.

To switch alarm on, gently pull out Alarm On/Off Button.

To switch alarm off, depress the Alarm On/Off Button.

**Note:** The alarm will sound for 15 seconds, before automatically switching itself off. After 2 minutes, the alarm will automatically repeat for a further 15 seconds before switching itself off.

## **For Electro-Luminescent Models**

Electro-Luminescent is state-of-the-art technology which allows you to read your watch under any lighting conditions.

To operate depress the Electro-Luminescent Button.

Note: The battery life will be affected by the number of times the E L display is operated; based on typical use of 2-3 times a day; the battery life expectancy is 2 years.

## Care of your watch

### Avoid temperature extremes

1. Avoid leaving your watch in direct sunlight or in extremely warm conditions for long periods of time: this will cause malfunctioning and shorten the life of the battery.
2. Do not leave your watch for long periods of time in extremely cold places; this may cause your watch to gain or lose time. Should it begin to gain or lose time, place your watch on your wrist to restore its original accuracy.

### Avoid wet conditions

1. Do not operate the buttons when your watch is wet, even on models marked 'Water Resistant'
2. Check case back markings and refer to the Resistance to water section.

continued...

**Avoid strong shocks**

1. This watch will withstand the bumps and jars normally incurred during sports activities.
2. Avoid dropping your watch on the ground or otherwise imparting severe shock to it.

**Avoid strong magnetic fields**

1. Keep your watch away from strong magnets
2. Generally, your watch is not affected by magnetic fields from household appliances such as television sets and stereo equipment.

continued...

## Care of your watch continued . . .

### **Avoid harmful chemicals, solvents & gases**

1. Avoid wearing your watch in the presence of strong chemicals, solvents or gases.
2. Avoid materials such as gasoline, benzene, paint thinner, alcohol, spray cosmetics, nail polish, nail polish remover, adhesives or paint.

### **Periodic inspection**

1. A regular 4 to 5 years service by an authorised Accurist technician will ensure trouble free operation.
2. Refer to the After Sales Service section for details.

continued...

**IMPORTANT**

1. Keep the batteries out of reach of infants and small children. Should accidental ingestion occur consult a doctor immediately.
2. Do not attempt to replace the battery yourself as this invalidates your guarantee.

**Keep you watch clean**


Wipe off any moisture that adheres to the case, glass or band with a soft, clean cloth.

## Bracelet Adjustment

The bracelet requires a small adjustment and the model has a Z-type clasp.



1. Depress the end of the spring bar on the centre clasp with a pin.



2. Relocate the spring bar in an alternative hole.

**The bracelet requires a significant adjustment or the model does not have a Z-type clasp.**

1. Use the enclosed wrist gauge to measure and mark the size of your wrist.
2. Return the completed wrist gauge with your watch
3. Follow the instructions in the After Sales Service section to return your watch for adjustment. Your watch will be adjusted free of charge.

## **International Service Agents**

### **International Service Headquarters**

Accurist Watches Limited, Asher House, Blackburn Road, West Hampstead,  
London, NW6 1AW

Tel: +44 (0)20 7447 3945, Fax: +44 (0)20 7447 3946

### **United Arab Emirates**

Al Abbas, P.O. Box 45999, Dubai, UAE

Tel: 00971 4 351 2440, Fax: 009714 351 2450

**Netherlands**

Sabre Nederland B.V., Ellermanstraat 23, 1099 BX Amsterdam, The Netherlands  
Tel: 0031 20 692 8888, Fax: 0031 20 665 2184

**Switzerland**

Nimex AG, Raffelstr 11, CH - 8045, Zurich, Switzerland  
Tel: 0041 44 462 91 91, Fax: 0041 44 462 91 81

**Norway**

Thune, Nils Hansensvei 2, N - 0667 Oslo, Norway  
Tel: 0047 22 70 08 40, Fax: 0047 22 70 08 41

**Kingdom of Saudi Arabia**

Al Asasyah, Sitteen Street, P.O. Box 19248 - 19249, Jeddah 21435

Tel: 00966 672 6826, Fax: 00966 676 2262

**N. Antilles**

J Best Jeweler, 2 Front Street, Philipsburg, St. Maarten, N. Antilles

Tel: 47 22 17 09 00, Fax: 47 67 53 54 43

**Cyprus**

A Chrysanthou Ltd, 35 Kappadokias Street, Strovolos 2028

Tel: 00357 22 512 122, Fax: 00357 22 512 880

## Resistance to water

| INDICATIONS ON DIAL OR CASEBACK                |                 | LIGHT SPRAY,<br>PERSPIRATION,<br>LIGHT RAIN<br>BATHING, ETC... | SWIMMING<br>ETC... |
|--|-----------------|--|--------------------|
| DIAL   | CASEBACK        |  |                    |
| -  | WATER RESISTANT | OK   | X                  |
| WATER RESISTANT<br>50M (5 ATM)                 | WATER RESISTANT | OK   | OK                 |
| WATER RESISTANT<br>100M (10 ATM)               | WATER RESISTANT | OK   | OK                 |
| WATER RESISTANT<br>150M (15 ATM)<br>AND DEEPER | WATER RESISTANT | OK   | OK                 |

| SKIN DIVING:<br>DIVING WITHOUT<br>AN AIR TANK | SCUBA DIVING:<br>DIVING WITH<br>AN AIR TANK | DIVING:<br>WHEN USING A<br>HELIUM ENRICHED<br>ENVIRONMENT |
|---|---|---|
| X   | X   | X   |
| X   | X   | X   |
| OK  | X   | X   |
| OK  | OK  | X   |



## Resistance to water

**IMPORTANT - NEVER PULL OUT THE CROWN WHEN THE WATCH IS WET.**

- Tighten screwlock crown completely
- Water resistance is not a permanent property. We strongly recommend you return your watch for resealing every 4 - 5 years and/or when changing batteries
- "Water resistant" may sometimes be abbreviated as "Water resist" or "WR".
- Never pull out the crown when the watch is wet.
- Always set the crown in the normal position.



## **Accurist Quartz Guarantee**

The terms of this guarantee provide rights that are in addition to your statutory rights and do not in any way limit or otherwise affect those statutory rights.

Your Accurist watch is guaranteed for 3 years from the date of original retail purchase against any malfunction of the watch movement due to defective materials or workmanship. This guarantee is applicable only to watches purchased in the United Kingdom. The guarantee is only valid if completed and dated at the time of purchase by your Accurist stockist.

To make a claim under the guarantee please return your watch directly to the International Service Headquarters at the address set out on page 18 or an International Service Agent.

**Accurist Quartz Guarantee continued . . .**

When returning your watch, please indicate brief details of the nature of the problem and the repair required.

We will, at our option, repair or replace your watch with a model of similar appearance or value.

After the expiry of this guarantee the Accurist Service Centre and International Service Agents are at your complete disposal.

We will be pleased to quote for routine maintenance, oiling or repair of your watch by our factory trained staff of experts.

This guarantee is provided by Accurist Watches Limited of Asher House, Blackburn Road, West Hampstead, London, NW6 1AW, England, United Kingdom

## After Sales Service

Each Accurist watch comes with a lifetime commitment to quality after sales service. Our award winning customer service team are dedicated to providing expert servicing from bracelet adjustments to full overhaul. We pride ourselves in identifying our customer's requirements and reacting to their individual needs. An expert watchmaker personally services each watch and Accurist guarantees quality at every step of the process.

## Payment & Postage Instructions

1. Complete the payment details form opposite.
2. Return the watch and payment details form together with this guarantee to the Accurist Service Centre address listed on page 18.
3. Enclose a cheque, postal order or MasterCard/Visa payment for **£5.00** payable to Accurist Service Centre. This covers return postage and insurance for loss or damage whilst in transit or undergoing repairs. No liability for loss or damage will be accepted without this remittance.
4. Please do not return your presentation box as we cannot guarantee its return.

Accurist Watches Limited  
 Asher House  
 Blackburn Road  
 West Hampstead  
 London, NW6 1AW

Telephone: +44 (0)20 7447 3900  
 Fax: +44 (0)20 7447 3949

Email: info@accurist.co.uk

For latest information please check our web site: [www.accurist.co.uk](http://www.accurist.co.uk)

Published May 2005

Folding

### For all other countries

1. Return the watch with payment to your nearest International service agent (see page 18).
2. Enclose a cheque for **€7.50**. This covers return postage and insurance for loss or damage whilst in transit or undergoing repairs. No liability for loss or damage will be accepted without this remittance.

Perforation

I enclose:  cheque  postal order  credit card,

debit card (issue no.      ) payment for **£5.00**

Card No:

|  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |
|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|
|  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |
|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|--|

Expires:

\_\_\_\_\_ / \_\_\_\_\_ / \_\_\_\_\_

Name:

\_\_\_\_\_

Address:

\_\_\_\_\_

Postcode:

\_\_\_\_\_

Signature:

\_\_\_\_\_